

SSI and SSII 1931-36		SSI all bodies	
	from	1931/10	
	1931/10	135005	
	1932/01	135043	
last 32 models	1932/07	135502	
first 33 models	1932/10	135503	
	1933/01	135595	
last 33 models	1933/09	136751	
first 34 models	1933/10	247001	
	1934/01	247206	
last 34 models	1934/08	248250	
first 35 models	1934/09	248251	
	1935/01	248552	
last 35 models	1935/09	249500	
first 36 models*	1935/11	248010	
	1936		
	1936/07	249500	

SSII all bodies		1931/10	
	from	1931/10	
	1931/10	124014	
	1932/01	124282	
	1932/10	134995	
	1932/10	150186	
	1933/01	154787	
	1933/07	159515	
	1933/10	300001	
	1934/01	300012	
	1934/08	300750	
	1934/10	300751	
	1935/01	300919	
	1935/08	301250	
	1935/11	300137	
	1936		
	1936/05	301249	

SSII Please Note:
1931-33 cars not built in chassis number order.
Chassis numbers shared with Standard Little Nine models of this period.

*1935 cars re-titled as '1936 models'

SS Jaguar 1935-37		1 1/2 litre saloon	
	from	1936/02	
	1936/02	20001	
last 36 models	1936/07	20700	
first 37 models	1936/08	20701	
	1937/01	21267	
last 37 models	1937/11	22250	

2 1/2 litre saloon tourer			
	from	1935/10	1936/04
	1935/10	10001	
	1936/01	10114	19001
	1936/07	11449	19060
	1936/08	11450	19061
	1937/01	12438	19085
	1937/07	13445	19105

SS 100 2 1/2 litre		1936/04	
	from	1936/04	
	1936/04	18001	
	1936/08	18033	
	1936/09	18034	
	1937/01	18051	
	1937/08	18126	

1 1/2 litre cars from 22195 were titled as "1938 models"

SS Jaguar 1937-40		1 1/2 litre saloon dhc	
	from	1937/10	1938/03
	1937/10	50001	
	1938/01	50003	56001
last 38 models	1938/07	50600	56042
first 39 models	1938/07	50601	56043
	1939/01	52197	56361
last 39 models	1939/06	53754	56643
first 40 models	1939/07	70001	*
	1940/01	70577	*
last 40 models	1940/07	70688	*

2 1/2 litre saloon dhc			
	from	1937/10	1937/10
	1937/10	40001	46001
	1938/01	40050	46002
	1938/07	40669	46061
	1938/08	40670	46062
	1939/01	41121	46198
	1939/06	41450	46273
	1939/07	80001	*
	1940/07	80128	*
	1940/07	80135	*

3 1/2 litre saloon dhc			
	from	1937/10	1938/03
	1937/10	30001	
	1938/01	30006	36001
	1938/07	30545	36105
	1938/08	30546	36106
	1939/01	30828	36183
	1939/07	31003	36238
	1939/07	90001	*
	1939/09	90068	*

*1940 drophead coupe models were given chassis numbers in the saloon car series

SS 100 2 1/2 litre 3 1/2 litre			
	from	1937/10	1937/11
	1937/10	49001	39001
	1938/01	49029	39024
last 38 models	1938/07	49050	39082
first 39 models	1938/08	49051	39083
	1939/01	49062	39095
last 39 models	1939/07	49064	39117
first 40 models	1939/07	49065**	38118**

**only one 1940 model of each