

Daimler DS 420 limousine

Engine number prefix 7M Engine numbers from 1001

Body number prefix 4M Body numbers from 1001

NB: Vanden Plas built cars 1968-79 also carry a 'Vanden Plas job number'

	rhd	chassis	lhd	
from	1968/04		1969/02	
1968	1M/1001			built at Vanden Plas, Kingsbury, London
1969	1M/1041		1M/20001	
1970	1M/1373		1M/20009	
1971	1M/1825		1M/20041	
1972	1M/2085		1M/20066	
1973	1M/2349		1M/20082	
1974	1M/2645		1M/20095	
1975	1M/2915		1M/20115	
1976	1M/3195		1M/20131	
1977	1M/3392		1M/20139	
1978	1M/3556		1M/20149	
1978/04	1M/3616		1M/20151	last pre VIN
1978/03	10001		10001	first VIN; LHD series to 10003 only, 78/04
1979/01	10091	400001		400001 in 1979/05
1979/11	10209			last VdP built limo
1980/02	200001	400021		first Browns Lane built; RHD/LHD mixed
1981/01	200117	400063		
1981/02	200129	400064		SAD code added to VIN prefix
1982/01	200275	400082		
1983/01	200374	400110		
1983/03	200400	400118		end of manual records

1984/01	200505		1984/01	400136	
1985/01	200645		1985/01	400170	
1986/01	200811		1986/01	400217	
1987/01	200935		1987/01	400268	
1987/02	200949		1987/02	400272	SAD code replaced by SAJ
1988/01	201074		1988/01	400306	
1989/01	201200		1989/01	400339	
1990/01	201365		1990/01	400362	
1991/01	201503		1991/01	400390	
1992/01	201611	last VIN	1992/01	400411	
1992/10	201631		1992/06	400425	last VIN